



SummitLite Lid
サミットライト リッド SOD-5301

取扱説明書

INSTRUCTION MANUAL



ご使用前に必ずお読みください。
Always read this instruction manual
before use and follow the instructions.



⚠ 注意 ご使用前に必ずお読みください。

- ご使用前に食器用洗剤を含ませた柔らかいスポンジでよく洗浄してからお使いください。
- ご使用後はよく洗浄して、水気を拭き取り乾燥させてから保管してください。
- 高い所から落とす等、急激な衝撃を与えないでください。破損や変形の原因になります。
- 電子レンジ・オーブン・食器洗い機・食器乾燥機では使用しないでください。
- ポットに組み合わせた状態(樹脂部品を取り付けた状態)で加熱しないでください。
- 100℃以上の高温がかかるような使い方はしないでください
- リッドを使用の際はポットへしっかりと押し込んで装着してください。リッドが浮いた状態ですとポットが抜け落ちるおそれがあります。
- リッドに着いているO-ringは外さずに使用してください。
- 食物や液体を入れた状態で逆さまや急激にポットを傾けないでください。
食物や液体を入れたまま逆さまにすると、飲み口などから食物や液体がこぼれる可能性があります。



IMPORTANT

Always read this instruction manual before
use and follow the instructions.

- Before use, wash thoroughly with a soft sponge soaked in dishwashing detergent.
- After use, wash thoroughly, wipe off any water and dry before storing.
- Do not subject the product to sudden impacts such as dropping it from a high place. This may cause damage or deformation.
- Do not use this product in microwaves, ovens, dishwashers or dish dryers.
- Do not heat the pot with any plastic parts attached.
- Do not expose the product to temperatures above 100°C/212°F.
- When using the lid, press it firmly into the pot and install it so that there are no gaps.
- Do not remove the O-ring attached to the lid when using.
- Do not turn the pot upside down or tilt it suddenly when food or liquid is inside. If the pot is turned upside down with food or liquid inside, the food or liquid may spill out of the spout.

発売元/PL保険加入済

新富士バーナー株式会社

〒441-0314 愛知県豊川市御津町御幸浜一号地1番地3

TEL0533-75-5000(代) FAX0533-75-5033

[https://shinふji.co.jp/](https://shinфуji.co.jp/)

E-mail:info@shinふji.co.jp

MADE IN CHINA

2024.3

SOTO USA, INC

Oregon USA

info@sotooutdoors.com

Phone: 503-314-5119

www.sotooutdoors.com